



D

С

В

А






24•4 CHANNEL BOARD

SR 24+4 SERVICE MANUAL MAAGEKIE.

50-15




24•4 CHANNEL BOARD

50-16

[]	
R154	
600	
R152	
(R254)	
600	
R <u>2</u> 52	
(R354)	
22	
R3 <u>5</u> 2	
(R454)	
<u> </u>	
R452 (	
(R554)	(51) (51) (51) (51) (51) (51) (51) (51)
600	
R5 <u>5</u> 2	
(R654)	R635 R617 C614 C615 C616 C641   R635 R617 C618 C614 C615 C616 C641   R635 C618 C614 C615 C616 C641 C614 C615 C616 C641
Reīs2	
R	
(R754)	
600	
R7252 (	
	<u> </u>

© 1995,© 1999 Mackie Designs Inc. All rights reserved.



This board is a snap-off from the board on the previous pages



